


F1010ER

A 55 A 55 F



Betriebsanleitung

Operating Instructions

Notice d'emploi

Instrucciones de servicio

1975

Gebürder Hoïder Maschinenfabrik
7418 Meizingen Western Germany
Telefon (07123) 2036 * Telex 07248210

Inhaltsverzeichnis

	Seite
Garantiebestimmungen	1
Beschreibung	7
Technische Daten	8
Bedienungsorgane und Kontrollgeräte	12
Vorbereitung zur Inbetriebnahme	12
Inbetriebnahme	15
Wartung und Pflege	19
Anbaulage für hinteres Kennzeichen	24
Hinweis zur Personenbeförderung	24
Geräteaushebung	24
Wie beurteile ich meinen Traktor	25
Empfehlungsliste für Öle	26
Wartungsübersicht	27
Störungstabelle	29
Fritzmeier Sicherheitsrahmen	31
Dreihwegeventil (Montage)	32
Bildnummern und Benennung	33
Forstaustführung	
Eintrommel-Forstseilwinde Type 5073-2	133
Doppeltrommel-Forstseilwinde Type 5073-7	135
Frontpoltereinrichtung	138
Contenu	
Indications importantes pour nos clients	68
Description	73
Caractéristiques techniques	74
Commandes et appareils de contrôle	78
Avant la mise en route	78
Mise en route	79
Entretien et soins	84
Plaque arrière d'immatriculation	89
Transport des personnes	89
Attelage pour outils 3 points normalisés	89
Comment évaluer votre tracteur?	90
Liste des huiles recommandées	91
Tableau d'entretien	92
Tableau des pannes	94
Cadre de sécurité Fritzmeier	97
Montage du robinet à trois voies 5080/1	98
No. des figures et description	99
Version forestier	
Treuil à un tambour type 5073-2	145
Treuil jumelé 5073-7	147
Dispositif porteur avant	151

Contents

	Page
Important Instr. f. customers	36
Description	41
Technical data	42
Operation levers and control instruments	46
Preparations for taking the tractor into service	46
Taking tractor into service	47
Service and maintenance	51
Position of rear licence plate	56
Transporting persons	56
Three-point linkage f. Cat. I implements	57
How to value a tractor	57
List of recommended oils	58
Service chart	59
List of possible engine troubles	61
Fritzmeier Safety Frame	63
Three-way valve	64
Illustration numbers and description	65
Forestry Version	
Single-drum forestry winch type 5073-2	139
Double-drum forestry winch type 5073-7	141
Front-mounted rolling/stacking unit	144
Indice	
Importante Información	100
Descripción	105
Datos técnicos	106
Organos de manejo y aparatos de control	110
Preparación para la puesta en funcionamiento	110
Puesta en funcionamiento	112
Entretienimiento y cuidados	116
Dispositivo para el montaje de la matrícula trasera	122
Transporte de personas	122
Alzamiento normalizado de aperos en tres puntos	122
Como juzgo yo a mi tractor?	123
Lista de recomendaciones de aceites	126
Cuadro para el entretenimiento	124
Tabla de averías del motor	127
Bastidor de seguridad (Fritzmeier)	129
Montaje de la llave de tres vías 5080/1	130
No. de figuras y descripción	131
Version forestal	
Tornu de cable de un solo tambor 5073-2	153
Torno gêmeo de cable 5073-7	155
Empujador	159

Engine and Tractor

A) Description

The experience achieved by the Holder Company in the course of more than 80 years of designing and manufacturing agricultural tractors, combined with the latest knowledge in engineering and production, have gone into your new Holder tractor, which will impress you with its economy, driving comfort, and high performance in all cultivations.

To keep your tractor ready for service at any time, please read this manual carefully, for it contains all instructions necessary for thorough care and maintenance of the tractor. **The operation manual belongs into the hands of the tractor driver.**

For all inquiries please indicate:

- a) Type of tractor e.g. A 55 resp. A 55 F
- b) Engine serial No. e.g. V3 20 500
- c) Tractor serial No. e.g. 35 30 101
- d) Date of sale: e.g. 2/4/74 and, if necessary, date of reclamation
- e) Tractormeter reading: e.g. 500 operation hours

The tractor serial No. is embossed on the type plate affixed to the dash panel (32. III. 4), or on the connection housing (31 III. 4). RH side in driving direction. The engine No. is to be found on the cylinder crankcase (68 III. 9) — exhaust side.

Technical data, illustrations and measurements, as stated in this manual, are not obligatory for us, and no claims can be derived from these. We reserve the right to make improvements in the tractors without changing this operation manual.

B) Technical Data

1. Engine

Manufacturers:

Type:

Design:

Mode of operation:

Combustion:

Number of cylinders:

Cylinder bore:

Stroke:

Cylinder capacity:

Compression ratio:

Air gap: (cold/warm)

Fuel consumption:

Cooling:

Air filter:

Lubrication system:

Oil pressure:

Oil filter:

Speed:

Idling speed:

Max. torque at 1800 min⁻¹ (rpm)

Capacity according to DIN 70020

Capacity according to SAE:

Transmission:

Clutch:

Fuel system

Fuel injection pump with regulator:

Fuel injection nozzle:

Injection pressure:

Fuel filter:

* Commencement of delivery of fuel injection pump:

Gebrüder Holder, Maschinenfabrik, 7418 Metzingen/Württ.
VD 3

in-line, vertical engine
four-stroke

Direct fuel injection

3

95 mm

95 mm

2020 cc

1 : 16,8

0,25 mm

245 g/kW/h (180 g/HP/h)

Water circulation cooling with thermostatically controlled pump

Oilbath air filter with cyclone preselector

Force-feed lubrication with gear pump

4 +1, bar atm.
-0,5

Change-cartridge in main stream (M & H - W 9.20)

2300 min⁻¹ (rpm)

800 min⁻¹ (rpm)

112,8 Nm (11,5 mKp)

27 kW (36 PS)

40 HP

Gear drive 8 forward, 4 reverse

Single-plate dry clutch KS 200 (make F & S) (with yellow springs)

Bosch O 400 463 093

Bosch DLL 140 S 591

175 bar (atm.)

Micronic filter cartridge — built into the tank —

12,6 mm b. T.D.C. (before top dead center)

Unscrew cover of injection pump. Turn regulator sleeve with gear ring forward by approx. 2/3. (Take care that markings of gears in gear control housing will correctly match).


* Detailed instructions for timing in VD2/VD3 Workshop Manual.

tt.

d pump

v springs)

with gear
gears in



Dimensions and measurements of tractors

(Dimensions in brackets relate to 10.5-20 tyres)

- Wheel base: 1450 mm
- Track widths: 1010/1250/1500 mm
- Overall width: 1250/1490/1740 mm (1280/1520)
- Overall length incl. 3-point linkage: 3120 mm
- Overall height without safety frame: 1340 mm (1290 mm)
- Overall height incl. safety frame: 1920 mm (1870 mm)
- Diameter of minimum inner turning circle: 4000 mm (3800 mm)

Weights:

A 55 with tyres

9.5-9-24 AS(6+8ply) 10.5-20 AS (8ply)

A 55 F with tyres

9.5-9-24 AS (8ply) 10.5-20 AS (8ply)

Empty weight with driver	1545 kg	1525 kg	1660 kg	1680 kg
total	890 kg	880 kg	960 kg	970 kg
front	655 kg	645 kg	700 kg	710 kg
rear	3000 kg	3000 kg	3000 kg	3000 kg
permissible total weight	1500 kg	1500 kg	1500 kg	1500 kg
on axle front	1500 kg	1500 kg	1500 kg	1500 kg
permissible load	1500 kg	1500 kg	1500 kg	1500 kg
on axle rear	1500 kg	1500 kg	1500 kg	1500 kg
permissible load	1500 kg	1500 kg	1500 kg	1500 kg

2. Transmission

- a) **Gearbox:** 8 forward speeds and 4 reverse speeds. Four-wheel drive via two differentials with spiral bevel gears, front diff-lock operated by spring-loaded foot pedal. (4 Ill. 1). Rear diff-lock operated by spring-loaded hand lever (9 Ill. 1).

b) Speeds at max. engine revs (2300 min⁻¹ (rpm))

	with rubber-tyres 9-24 (6 and 8 ply rating)	with rubber tyres 10.5-20 (8 ply rating)
Forward:		
1st speed	1,30 km/h	1,10 km/h
2nd speed	2,20 km/h	2,00 km/h
3rd speed	3,60 km/h	3,20 km/h
4th speed	5,70 km/h	5,10 km/h
5th speed	4,70 km/h	4,20 km/h
6th speed	8,10 km/h	7,20 km/h
7th speed	13,10 km/h	11,70 km/h
8th speed	21,00 km/h	18,80 km/h
Reverse:		
1st speed	1,80 km/h	1,50 km/h
2nd speed	3,00 km/h	2,70 km/h
3rd speed	4,90 km/h	4,40 km/h
4th speed	7,80 km/h	7,00 km/h

- c) **Tractormeter:** (2 Ill. 3) Registering ground speed, engine and P.T.O. rpm. and hours. The tractormeter registers one hour based at an engine speed of 1650 min⁻¹ (rpm).
- d) **Diff-lock:** Foot-pedal operated front-axle diff-lock. (4 Ill. 1). Hand lever operated rear-axle diff-lock.
- e) **P.T.O.:** Standardised P.T.O. with 540 min⁻¹ (rpm) at 2100 min⁻¹ (rpm) of the engine or 590 min⁻¹ (rpm) at 2300 engine min⁻¹ (rpm).
- f) **Steering:** ZF type pivotal steering, acting on all four wheels, with full hydromatic steering assistance.
- g) **Brakes:** Acting on all four wheels, two independent braking systems, footbrake and handbrake acting on all four wheels. The handbrake consists of a ratchet lever.

h) Trailer hitch

- i) **Hydraulics:**
Max lifting
Capacity of

Working pre
Hydraulic o

Control valv
Oilfilter:

- k) **Implement i**
standards DI

- l) **Electrical sy**

Starter:

Dynamo:

Dynamo vol

Dynamo cap

Mode of regi

Battery capa

Headlights:

Front traffic

Tail lamp:

Braking light

Rear traffic l

Licence plat

Pilot light sy

Rear reflecto

Horn:

Socket for tr

Socket for w

Combined cc

al bevel
spring-

(8 ply rating)

meter registers

lock.

r-1 (rpm)

nce.

cting on all

h) **Trailer hitch:** adjustable for height and revolving, with a pistol-type handle grip for one-man operation.

i) **Hydraulics:** Holder two-cylinder hydraulics with Bosch gear pump.

Max lifting capacity — as measured on lower linkage arm of the field bar: 14000 N (1400 kg)

Capacity of hydraulic pump: with hydromatic steering 11 cc per rev. (26 l/min) at 2300 min⁻¹ (rpm)

Working pressure: max. engine speed

Hydraulic oil supply tank: situated in front gearbox 175 bar (atm.)

for temperatures below —10° C

Control valve: HD-B-SAE 20 engine oil
Oilfilter: HD-B-SAE 10
Bosch HY/SEA 5/175/1
situated in return flow pipe

k) **Implement linkage:** Standard Cat. 1 three-point-linkage with drawbar. Corresponding with German specification standards DIN 9674.

l) **Electrical system (12 Volt system)**

Starter:

Dynamo:

Dynamo voltage:

Dynamo capacity:

Mode of regulation:

Battery capacity:

Headlights:

Front traffic lights:

Tail lamp:

Braking light:

Rear traffic light

Licence plate light:

Pilot light system

Rear reflectors:

Horn:

Socket for trailer lighting:

Socket for windscreen wiper of tractor cab:

Combined control instrument:

Bosch 0001 362 012 Type JF
Bosch EH (R) 14 V 11 A 19
12 V

90 W

Voltage regulation

88 Ah

2

2

2

1

yes

2

yes

yes

yes

yes

C) Operation levers and control instruments

Ignition lock

The ignition lock allows the selection of three different positions with the ignition key:

0 = engine clear for starting, engine can be started

1 = parking light on

2 = dimmed headlight on

No.	III.	Description of part:	No.	III.	Description of part:
1	3	Combined control instrument	34	4	Cut-out rod
2	3	Tractormeter	26	4	Hydraulic operation lever
15	2	Ignition lock with ignition key	27	4	P.T.O. selector lever
17	2	Warning light impulse transmitter	6	1	Gear selector lever
16	2	Glow starter switch	7	1	Selector lever (preselection)
19	2	Fuse box	4	1	Foot-pedal for diff-lock operation (front)
5	1	Traffic light switch	9	1	Hand lever for diff-lock operation (rear)
35	4	Horn button	10	1	Clutch pedal
3	1	Hand throttle lever	30	4	Foot brake pedal
29	4	Foot lever (gas)	33	4	Hand brake

Driver seat

Can be adjusted to the operator's weight. Adjustment with lever (8 III. 1).

(W) = soft springing

(H) = hard springing

} Fix lever (Y III. 1) accordingly.

D) Preparations for taking the tractor into service

For the first 20 hours do not operate engine under full load for a prolonged period of time.

Before taking your tractor into service, examine it thoroughly for traffic and operation safety. Make the following check-up:

- a) Fuel supply
- b) Oil level in
 - For temperature from -10 above + 20
 - Use only recommended oil
- c) To check
- d) All four tires

- e) Check lights
- f) Check trailer
- Make a short
 - a) Clutch and
 - b) Foot and
- Repair any irregularities when driving

E) Taking 1

1. Preparations for taking tractor into service

Starting at night

- a) Move hand lever to the "P" position
- b) Insert key

- a) Fuel supply in tank (36 III. 5)
- b) Oil level in engine (42 III. 7)

For temperatures below -10°C
from -10°C to $+20^{\circ}\text{C}$
above $+20^{\circ}\text{C}$

HD-B-oil SAE 10 W
HD-B-oil SAE 20
HD-B-oil SAE 30

Use only HD-B oils for diesel engines. HD-B oils are high-grade branded oils for diesel engines corresponding to the specification MIL-L-2104 B. Please ask your Holder distributors or dealers for advice. List of recommended oils see page 60.

In order to avoid damages caused by the use of inferior lubrication oils, we recommend to use only branded oils of the large oil companies, and to stick to the initially chosen brand.

- c) To check cooling water level, remove radiator cap (46 III. 6).
- d) All four tyres must have the same pressure:

9-24 AS (6ply)	1,5 bar (atm.)
9-24 AS (8ply)	2,5 bar (atm.)
10.5-20 AS (8ply)	2,5 bar (atm.)
- e) Check lighting system
- f) Check trailer hitch

Make a short trial run in order to control:

- a) Clutch and steering
- b) Foot and hand brakes.

Repair any irregularities at once!

When driving on public roads please pay strict attention to your local traffic regulations.

E) Taking tractor into service

1. Preparation

Shift gear selector lever into neutral (6 III. 1)

Starting at normal temperatures

- a) Move hand throttle lever (3 III. 1) to approx. half revs.
- b) Insert key (15 III. 2) in ignition lock till charging lamp (21 III. 3) lights up red, and oil pressure indicator (22 III. 3) lights up yellow.

Make the

n)
operation (front)
deration (rear)

- c) Pull out glow starter button (16 Ill. 2) as far as stop. The starter is now in operation. As soon as engine has sprung to life, release the button. **Never operate the starter with running engine.** If engine fails to fire after 10 seconds, release button and repeat the starting procedure. After the engine has sprung to life, glow starter indicator (22 Ill. 3) and oil pressure indicator (22 Ill. 3) must go out.
- d) Select desired engine speed with the hand throttle lever (3 Ill. 1), resp. with the foot gas pedal (29 Ill. 4).

Starting at low temperatures

- a) Move hand throttle lever (3. Ill 1) to approx. half revs.
- b) Insert key (15 Ill. 2) in ignition lock till charging lamp (21 Ill. 3) lights up red, and oil pressure indicator (22 Ill. 3) lights up yellow.
- c) Pull glow starter button (16 Ill. 2) out to first position and hold for approx. 1 minute (preglow), i.e. till glow starter indicator (18 Ill. 2) lights up bright red, then pull out button as far as stop. (The starter now turns over the engine). After the engine has come to life, glow starter indicator (21 Ill. 3) and oil pressure indicator must go out.
- d) Select desired engine speed with the hand throttle lever (3 Ill. 1), resp. foot gas pedal (29 Ill. 4).

2. Driving

Before using the gear lever, the hand throttle lever resp. foot gas pedal (3 Ill. 1 and 29 Ill. 4) should be shifted to neutral. Then depress clutch pedal (10 Ill. 1) (declutch). Preselect desired gear by means of the presselector lever (7 Ill. 1). Shift gear lever (6 Ill. 1). (See gear selection diagram Ill. 16). Release hand brake (33 Ill. 4).

If the gear proves difficult to engage, depress clutch pedal (10 Ill. 1) a second time (never use force), release clutch pedal (10) slowly. Control speed within desired gear range with the hand throttle lever (3 Ill. 1), or with the foot gas pedal (29 Ill. 4). (Whilst driving, take your foot off the clutch pedal). Security can be increased

With the hydraulically assisted steering system, uncalculably high pressures might develop

- a) if the permissible steering angle is not maintained
 - b) when passing over obstacles with high speed, or pushing away heavy objects with the drive wheels.
- In such events, the steering system is bound to be overstressed and can be damaged.

Never let tractor run in unventilated space!

Carbon oxides are scentless and invisible.

Driving on steep slopes

We draw your particular attention to the fact that driving on extremely steep slopes, whether in line with, or diagonally across the slope, is at your own risk!

Take particular care whilst using the tractor — set on narrow track, and with heavy implements attached — in uneven territory, specially when turning the machine downhill on slopes.

Should it happen following:

An open inlet valve be drained through Security can be Holder dealer for

Stationary operation For a lengthy stop pump, take care We recommend

3. Braking

The foot brake use of the tractor outward turn or use suitable chocks When using the

Trailer lighting: and brake lights

4. Diff-lock

To obtain power differential gear lever operated (Attention! With ahead only.

5. Adjustment

To alter the trailer always point to

jine

to

to life,

III. 4).

icator

a. till

ir now

ressure

3 shifted
selector
I. 4).

elease

), or with
reased

Should it happen that the machine has turned over under an extreme working condition, pay attention to the following:

An open inlet valve allows the oil of the air filter to enter the cylinder, blocking up the engine. This oil must be drained through the opening of the nozzle holder.

Security can be increased by using Holder hub spacers, or Holder wheel ballast weights. Please ask your Holder dealer for advice

Stationary operation

For a lengthy stationary operation of the tractor, i.e. when using the P.T.O., for instance to drive a water pump, take care that the machine stands on level ground.

We recommend to increase the oil level of the rear gearbox by approx. 2 litres.

3. Braking

The foot brake (30 III. 4) is used when the tractor is moving. Test the brakes for proper function before each use of the tractor. The brakes have the advantage of acting at any time uniformly on all four wheels. A slight outward turn of the hand ratchet lever (33 III. 4) releases the handbrake. When parking the tractor on a slope, use suitable chocks, turn the engine off, and shift the gear lever to a low gear.

When using the tractor with an attached trailer, pay attention to your local traffic and safety regulations.

Trailer lighting: Please pay attention to local traffic and safety requirements. Where rear reflectors, traffic, and brake lights, are required by law, a 7-pole plug DIN 72576, can be supplied.

Pay attention to your local traffic and safety regulations.

Driving with attached trailers, specially drive axle trailers, or other trailed vehicles, is at your own risk.

4. Diff-lock

To obtain power transmission through both, rear or front wheels, when working in soft, slipping ground, the differential gear can be locked. The front diff-lock is pedal-operated (4. III. 1), and the rear diff-lock is hand lever operated (9 III. 1).

Attention! With locked differential, i.e. if the wheels are rigidly locked, the tractor must be steered straight ahead only.

5. Adjustment of track width

To alter the track width, change over both pairs of wheels from right to left. The arrow on the tyres must always point to forward driving direction.

track widths. The tyre size must be the same for all four wheels. Ranges of adjustment see on page 29.

Tyre pressure with tyres: 9-24 AS (6ply) 1,5 bar (atm.), 9-24 AS (8ply) 2,5 bar (atm.), 10.5-20 AS (8ply) 2,5 bar (atm.) Check wheel nuts for tightness regularly, specially after having changed over the wheels. The steering angle must always remain as adjusted by the manufacturers.

Do not use larger tyre sizes for the following reasons:

- a) The permissible speed must never be exceeded
- b) Sufficient distance between the tyres must remain at maximum steering angle
- c) Larger tyres will overstress the transmission.

Track widths (measured from wheel centre to wheel centre)

To avoid an overstress of the bearing points, the max. track widths allowed from the works must never be exceeded.

Max. track width = 1500 mm — wheel spacers type 5092-2 (125 mm)

A 55 F max. track width = 1250 mm.

6. Wheel ballast weights

A 55 50 kg for each wheel, front or rear, with A 55 F in front only.

The weights must always be used in pairs. If ballast weights are used, water in the tyres, or other ballasts, are not allowed.

Filling the tyres with water

Water filling valve

The A 55 tractor both, with tyres 9-24 and 10.5-20, has a water filling valve for standard equipment.

Filling in water (III. 15a)

Jack up the tractor and turn the wheel till the air valve is on top. Remove the valve insert and screw the water filling valve into the hose valve. Connect the water hose, and let water flow in till it comes out on the little ventilation valve — L —. Then remove water filling valve, refit valve insert, and pump up the tyre to the prescribed pressure.

Draining the water from the tyres (III. 15a)

Jack up the tractor, remove valve insert, and drain the water. To drain completely, fit combined valve, and pump up air. The air pressure will cause the last drop of water to come out of the ventilation tube. Then remove combined valve, refit valve insert, and pump up tyre to required pressure.

Water filling i
When frost is

7. Hydraulic

The hydraulic
A forward pu
of the imple
travel, the lev

nously worki

Caution: Whe
discharged, i.
ments, alway
The distribut

8. Stopping t

Let engine ru

9. Shutting e

Shift hand th
Remove ignit

F) Service a

(See also Serv

Always bear i
Thorough ser
become neces

1. Engine

a) Oil change
oil drain sc
should still

age 29.
AS (8ply)
wheels. The

st never be

r ballasts,

nent.

rew the
s out on the
ie tyre to the

l valve, and
be. Then

Water filling in winter

When frost is expected, add an anti-freeze mixture to the water used for filling the tyres.

7. Hydraulic power lift

The hydraulic lift arms (26 Ill. 4) are actuated by means of hydraulic lever (73 Ill. 13) via the control valve.

A forward push of the lever („Senken“) will cause lowering, and a rearward pull („Heben“), will cause lifting, of the implements. In intermediate position, the implement is locked in instant height. At the bottom of the travel, the level is held, and the control element in its working (floating) position. The hydraulic pump continuously working, the hydraulic lever must only be used for lifting or lowering the implements.

Caution: When parking the tractor unattended (even during working breaks), the hydraulic cylinders must be discharged, i.e. the implements must be lowered to the ground, in order to prevent accidents. When using implements, always pay attention to the corresponding local traffic regulations!

The distributor (85 Ill. 5) has a throttle valve plate for standard equipment.

8. Stopping tractor

Let engine run idle, declutch, shift gear lever (6 Ill. 1) to neutral position „0“. Put on hand brake.

9. Shutting engine off

Shift hand throttle lever (3 Ill. 1) forward to neutral. Pull cut-out lever (34 Ill. 4) till engine shuts off. Remove ignition key.

F) Service and Maintenance

(See also Service Chart on pages 58/59)

Always bear in mind:

Thorough service will pay! Oil changed in time and punctual lubrication are cheaper than repairs which become necessary due to negligence!

1. Engine

a) **Oil change** — for the first time after 20 operation hours, thereafter every 150 operation hours. Remove oil drain screw (A1 Ill. 9) and (86 Ill. 9) with tractor standing on level ground. Drain oil (to do so engine should still be warm so that the old oil drains well). Clean oil drain screw and magneto plug.

Replace filter element (67 Ill. 9). When fitting new cartridge the gasket must be flush.

Attention! With every engine oil change, fit a new filter element Part No. of change filter cartridge 000 022 96 51 (M & H No. W 9.20).

Refit oil drain screw (A1 Ill. 9) in oil sump, and oil drain screw (86 Ill. 9) in steering box, and tighten well. Only after this has been done, fill in fresh oil through the oil filler plug (43 Ill. 6), (observe utmost cleanliness). The ventilation filter of the oil filler plug (43 Ill. 6) must also be cleaned with every oil change. After the oil change, make a short trial run. Thereby, observe oil pressure indicator (22 Ill. 3). Check gasket of filter element! After this, check oil level with shut-off engine. Max. diprod mark (42 Ill. 7) can be exceeded by approx. 5 mm.

Oil Filling quantities: 6,0 Ltr.
Incl. micro-mesh oil filter.

below -10° C	HD-B SAE 10
up to +20° C	HD-B SAE 20
above +20° C	HD-B SAE 30

Clean the ventilation filter of the fuel injection pump (41 Ill. 5) after every 150 hours of operation in diesel oil.

b) Oilbath air filter: Clean according to dust development, if necessary daily. Remove oil basin (70 Ill. 10), and wire gauze insert (69 Ill. 10), and clean in diesel fuel. Let wire gauze drip dry, and top-up to mark with fresh engine oil.

Clean cyclone. Pay attention to outlet port. (Situating below).
Check, resp. clean inlet pipe in air filter.

c) Cooling system: Check cooling water level daily, possibly when engine is cold. Be careful if engine is still warm. Lift radiator cap (46 Ill. 6) carefully as far as stop, and let excess pressure escape. Only then remove radiator cap entirely. The cooling agent thermometer (25 Ill. 3) has a three-colour scale. **White:** sub-temperature of engine. **Green:** normal working temperature. **Red:** engine temperature too high — shut-off at once! Excessive cooling water temperature can have the following causes:

dirty radiator, insufficient cooling water, defective water pump, thermostat not responding, V-belt slack or torn. If frost is expected, add anti-freeze mixture, or have cooling water concentration checked.

Cleaning radiator: Remove insects and dust deposits by blowing through radiator fins from the engine side with compressed air.

Draining cooling water: Open drain screw (Aw Ill. 9) at the radiator bottom.
Open drain screw (66 Ill. 9) at the engine.

d) V-belt
2 V-belts
both s
tainer

We recon
e) Regul:
on coi
servic

f) Inject
device

g) Valve
After

therea
Adjus

The se
Direct
VD 3

Adjus

Adjus

Adjus

h) ZF spi
The h

assista
can st

Check

Readji
measu

well.

aniness).

the oil

element!

x. 5 mm.

ines

diesel

10),

irk

still
remove

tem-
ff at

black

ne side

d) V-belt: The V-belt (60 Ill. 9) has the right tension, if you can press it down with your finger between the 2 V-belt pulleys of ventilator and dynamo (62 Ill. 9) by approx. 1 cm. To retighten the V-belt, slacken both screws (61 Ill. 9) on the adjustment shackle as well as the two screws (63 Ill. 9) on the dynamo retainer. Then press dynamo outwards, till the V-belt has the right tension. Thereafter, retighten screws.

We recommend:

e) Regulator of fuel injection pump — (50 Ill. 7) — after every 300 hours of operation, drain excessive oil on control plug (49 Ill. 7). Have fuel injection pump, injection nozzles, and regulator, checked by a Bosch service station after every 1500 service hours. Have oil in regulator renewed.

f) Injection nozzles: Dismantle after every 600 operation hours, clean, and check with Bosch nozzle testing device (Test pressure 175 bar (atm.).

g) Valve clearance (Have valve clearance checked and adjusted by an expert only!)
After the first 20 operation hours, check valve clearance with a feeler gauge (warm and cold 0,25) thereafter — under normal working conditions — check valve clearance after every 300 service hours.

Adjustment of valve clearance:

The sequence of cylinders, as mentioned below, is as seen from the radiator side.
Direction of rotation of engine „clockwise” as viewed from the V-belt pulley of the crankshaft.
VD 3

Adjustment of cylinder I valves: at the point of opening of cylinder III outlet valve.

Adjustment of cylinder II valves: at the point of opening of cylinder I outlet valve.

Adjustment of cylinder III valves: at the point of opening of cylinder II outlet valve.

The clearance between rocker arm and valve — on both, inlet and outlet valve — should „only just” allow the feeler gauge (84 Ill. 14) to be inserted. If the clearance proves to be either too narrow, or too wide, slacken counter nut (83 Ill. 14) and readjust setcrew in a way, which will allow, with counter nut retightened, the feeler gauge to be removed without resistance.

h) ZF spindle-type hydromatic steering

The hydromatic steering assistance, considerably reduces the force required for steering. Steering assistance responds only if the engine is running. Should the steering aid cease to function, the tractor can still be steered, but with increased force. (Oil change see under the heading „Front transmission”.)

Check steering angle to both sides with gauge (P Ill. 4a). Measurement 1150 mm.

Readjustment: Slacken hexagon nut (1374 Ill. 4a) and adjust thread pin (1375 Ill. 4a) so that the check measurement of 1150 mm is obtained when the thread pin meets the forked piece (1386 Ill. 4a).

i) Ventilation („bleeding”) of fuel system

The fuel system must be ventilated („bled”) if:

- a) fuel tank is empty
 - b) fuel pipes have been disconnected, or removed, i.e. if air has entered the pipes, or the intake chamber of the fuel injection pump (e.g. if fuel tank has been run dry).
- Slacken the ventilation screw (51 Ill. 7) of the fuel injection pump. The fuel must come out without bubbles. Then tighten ventilation screw.

k) Renewing fuel filter

The fuel filter cannot be cleaned. (Part No. of filter element: 000 022 6751, M & H No. 7070)

The fuel filter, built into the fuel tank (36 Ill. 5) must be replaced, depending on the degree of dirt, approx. after every 300 hours of operation.

As soon as the fuel filter has been removed, the valve in the fuel tank automatically prevents the fuel from entering the tank. After the fuel filter has been refitted, the fuel flow into the tank is resumed.

Fuel

It is absolutely essential, to use only high-grade fuel. Fuels corresponding with the German specification standards DIN 51601, or the British specification standards BS 2859: 1957 class A — high speed, will fulfill all requirements of a good fuel. The proportion of sulphur should not exceed 0,5 %.

Attention! To avoid trouble during the cold season, we recommend that you provide for winter fuels well in time. Your filling station will advise you.

l) Battery maintenance

Regular control and renewal of the acid level is of particular importance.

The liquid level must be 15 mm above upper edge. Use only distilled water for refilling. Check every 4 weeks, during the warm season every two weeks.

At this opportunity we recommend to also check tight fitting of battery and terminals. This is particularly important to obtain sufficient current for starting.

Avoid oxidation by thoroughly cleaning the terminals and by greasing them, particularly at the lower side, with acid-free battery grease.

An entirely charged battery is particularly important for starting in cold weather because then more energy is required than in warm seasons. If the tractor is used for short periods only, the charge via generator is insufficient and the battery must be charged with a charging unit now and then.

a) Grease the other lube

and in the tractor so that the commercial

b) Front gear

Change oil contains A 55 = 7

Draining

- 1. Press | Move
- 2. Open
- 3. Drain

Refilling

- 1. Fill in
- 2. Start | lock.
- 3. Refill
- 4. Lift at
- 5. Shut | (front sight |

c) Rear gear

Change oil SAE 80
If the tractor is drained
If the tractor is increased 1

amber
out bubb-

uel from

cation
will

els

Y

icular-

er side,

e energy
or is

2. Transmission

a) Grease the lubrication nipples (Sk) of the universal cross after every 1500 operation hours. Grease all other lubrication nipples (S) after every 300 operation hours. Under unfavourable working conditions, and in tropical areas, lubrication should be effected in shorter intervals. To lubricate the universal crosses, the tractor must be in maximum steering angle to one side, and the position of the universal shaft must be so that the grease nipples are visible. Grease guns with spacer pieces, that permit to reach the nipples, are commercially available.

b) Front gearbox — (hydraulic oil supply tank).

Change oil for the first time after 150 hours, thereafter every 1500 operation hours. The front gearbox contains normally HD-B SAE 20 engine oil, in case of temperatures below 10° C, HD-B SAE 10 oil. A 55 = 7,0 Ltr. + 2,0 Ltr. in hydromatic steering, and hydraulic system.

Draining oil:

1. Press hydraulic lever (73 Ill. 13) of hydraulic power lift down as far as stop. Move hydraulic operation lever to lowering „Senken“ (26 Ill. 4)
2. Open drain plug (A Ill. 1) of steering, and turn steering wheel left and right to steering lock.
3. Drain oil on front transmission through drain screw (A2 Ill. 11).

Refilling oil and ventilation:

1. Fill in oil on filler sight glass (E2 Ill. 4) 7,0 Ltr. HD-B oil, SAE 10 or 20.
2. Start engine and let it run in idling speed. Turn steering wheel several times from right to left steering lock. Ventilation is automatically effected through the ventilation filter in the front gearbox.
3. Refill with approx. 2,0 Ltr. HD-B oil.
4. Lift and lower hydraulics several times under load.
5. Shut engine off. Lower hydraulics. Check oil level on filler sight glass (E2 Ill. 4), with lowered hydraulics (front loader). The system has been correctly ventilated, if the oil level is visible at the mark of the filler sight glass. If necessary, top-up to mark.

c) Rear gearbox

Change oil for the first time after 300, thereafter every 1500 operation hours. The rear gearbox contains SAE 80 gear oil = 9,0 Ltr.

If the tractor stands on level ground, the oil must at least be visible at the centre of the sight glass (K Ill. 4). Drain screw (A3 Ill. 13). Filler screw (E3 Ill. 1).

If the tractor is used stationary for some period of time, e.g. for driving a water pump, we recommend to increase the oil level by approx. 2 litres, and to stand the machine on level ground.

FRANÇAIS

ESPAÑOL

FRANÇAIS

ENGLISH

DEUTSCH

ESPAÑOL

d) Reduction gears

Check oil level on control plug (K III. 5 and III. 13). If necessary, top-up with SAE 80 gear oil.

3. Brakes, Clutch, Lighting system

Brakes, clutch and lighting system must be in full order at any time.

a) Brakes — Clutch

Check function before each use. Apply every week a few drops of oil to the clutch operating shaft, brake pedal bearings, etc.

b) Lighting

Have lighting system checked after every 150 operation hours (Wiring diagramme III. 20).

Resetting clutch

In the course of time, lost motion will be reduced owing to wear of the clutch plate linings, resp. increased through wear of the graphite seal. Lost motion of the clutch pedal must be regularly controlled and reset. At its press-fit, hold threaded part (11 III. 1) tight with a pair of pliers, and adjust lost motion to approx. 15–20 mm by turning the collar nut (12 III. 1). Lost motion of the clutch pedal is the way the pedal takes before a resistance can be felt.

Attention! Unnecessary sliding of the clutch will cause premature wear. Therefore, do not use the clutch pedal as a foot rest.

4. Washing the tractor

When washing the tractor down with water, disconnect battery terminals, or still better, remove battery entirely. Protect air filter opening, and fuel injection pump, from a direct contact with water.

G) Position of rear licence plate on four-wheel drive tractor

Traffic regulations in Germany prescribe for agricultural and forestry machines with a speed not exceeding 30 km/h a licence plate of the size 240 x 130 mm. In order to be correctly lighted by the licence plate lamp, the plate must be fitted to the tractor as shown on illustration No. 15.

H) I ran

Traffic re
pay atter

I) Thre

The three
made wit
implemer
be alterec

K) How

A motorc
operation

H) Transporting persons

Traffic regulations in Germany prohibit the transporting of persons unless a suitable seat is provided. Please pay attention to your corresponding local regulations.

I) Three-point linkage for standard Cat. I implements

The three-point linkage is suitable for attachment of standard Cat. I implements. Horizontal adjustment is made with the crank handle (79 Ill. 13). Whilst adjusting, please discharge hydraulics. Lateral swing of the implement is adjusted on the check chains (74 Ill. 13). The length of the upper linkage arm (77 Ill. 13) can be altered.

K) How to value a tractor

A motorcar is generally valued according to driven kilometers and age. A tractor is best valued according to operation hours and age, with the following guiding principles:

1 operation hour	=	75 driven km of a motorcar
10 operation hours	=	750 driven km of a motorcar
250 operation hours	=	18750 driven km of a motorcar
500 operation hours	=	37500 driven km of a motorcar
1000 operation hours	=	75000 driven km of a motorcar
2000 operation hours	=	150000 driven km of a motorcar
2500 operation hours	=	187500 driven km of a motorcar.

ceeding
late lamp,

attery

clutch pe-

increased
d reset. At
ox. 15-20
s before

aft, brake

L) List of recommended oils

The oils to be used with Holder diesel engines must be in conformity with the American Military Specification MIL-L-2104 B. The following oils correspond to the above mentioned specification and are recommended by us:

1. ARAL		
ARAL diesel engine oil SAE 10 W	= SAE 10 W	
ARAL diesel engine oil SAE 20 W/20	= SAE 20	
ARAL diesel engine oil SAE 30	= SAE 30	
2. BP		
BP Vanellus-T-SAE 10	= SAE 10 W	
BP Vanellus-T-SAE 20	= SAE 20	
BP Vanellus-T-SAE 30	= SAE 30	
3. ESSO		
Essolube HDX SAE 10 W	= SAE 10 W	
Essolube HDX SAE 20	= SAE 20	
Essolube HDX SAE 30	= SAE 30	
4. FINA		
FINA Delta Motoroil SAE 10	= SAE 10 W	
FINA Delta Motoroil SAE 20	= SAE 20	
FINA Delta Motoroil SAE 30	= SAE 30	
5. GASOLIN		
GASOLIN HD SAE 10 W	= SAE 10 W	
GASOLIN HD SAE 20 W/20	= SAE 20	
GASOLIN HD SAE 30	= SAE 30	
6. MOBIL-OIL		
MOBIL Delvac Oil 1210	= SAE 10	
MOBIL Delvac Oil 1220	= SAE 20	
MOBIL Delvac Oil 1230	= SAE 30	
7. SHELL		
SHELL Rotella Oil S SAE 10 W	= SAE 10 W	
SHELL Rotella Oil SAE 20 W/20	= SAE 20	
SHELL Rotella Oil S SAE 30	= SAE 30	
8. VALVOLINE		
VALVOLINE Super HPO SAE 10	= SAE 10 W	
VALVOLINE Super HPO SAE 20	= SAE 20	
VALVOLINE Super HPO SAE 30	= SAE 30	
9. VEEDOL		
VEEDOL Engine oil (Heavy duty plus)	= SAE 10 W	
HD 901 Special	= SAE 10 W	
VEEDOL Engine oil (Heavy duty plus)	= SAE 20	
HD 902 Special	= SAE 20	
VEEDOL Engine oil (Heavy duty plus)	= SAE 30	
HD 903 Special	= SAE 30	

Our foreign agents are requested to check the oils they have so far recommended, and which are being used by Holder tractor owners, in the light of these instructions. This means, that the relevant mineral oil companies should be asked whether their recommended oils are in conformity with the American Military Specification MIL-L-2104 B.

M) Service Chart We recommend to have the following services carried out by an accredited Holder Workshop.

1st Service

A

to be carried out by agent immediately upon receipt, and before taking tractor into service.

B

When handing tractor over to client. If possible, carry out all jobs, and give all explanations, in the presence of the tractor owner, or his authorised person, and the tractor driver.

C

After every 8 to 10 operation hours (daily)

D

After the first 20 operation hours

= SAE

= SAE

= SAE

10 W. = SAE

W/20 = SAE

30 = SAE

AE 10 = SAE

AE 20 = SAE

AE 30 = SAE

duty plus) = SAE

duty plus) = SAE

duty plus) = SAE

= SAE

Grease all lubrication nipples.

Check oil level in engine and gearbox.

Engine: Optimum oil level upper diprod mark. Use only clean, branded

HD-B oils for diesel engines. For temperatures below -100° C HD-B

SAE 10, from -100° C up to +200° C

HD-B SAE 20, above +200° HD-B

SAE 30

Rear gearbox: oil level centre of sight glass. SAE 80 gear oil.

Front gearbox: Check oil level on filler sight glass! HD-B SAE 20 engine oil, for temperatures below

-100° C HD-B SAE 10.

Reduction gears A 55: Check oil level on control plug. SAE 80 gear

oil.

Retighten wheel nuts.

Check oil level in air filter, if necessary top-up with engine oil.

Check cooling water level. If frost is expected, check cooling water

concentration!

Check tyre pressure

Trial run engine, check function of tractor and hydraulic system.

1. Check tractor for completeness. Check tools.

2. Instructions according to operation manual.

3. Before taking tractor into service, in the presence of client:

a) Check oil level of engine, explain oil change. (Point out oil filter). Observe scrupulous cleanliness when filling in oil.

b) Explain cooling system. In danger of frost, check cooling water concentration!

c) Check V-belt tension.

d) Rear and front transmission, show sight glass, resp. filler screw, and explain oil change.

e) Reduction gears A 55, point out overflow control screw, and lubrication points.

f) Show lubrication nipples, oil control screws, and lubrication points.

g) Explain air filter and ventilation of fuel pipe.

h) Check oil level of air filter, and explain cleaning.

i) Point out to battery maintenance.

k) Show steering stop bolts, and explain their function. Check steering angle measurement.

4. Check tyre pressure.

5. Check function of engine, gearbox, diff-lock, give practical demonstration of hydraulics. Point out to correct way of parking tractor - discharging hydraulics, lowering of implements (danger of accidents).

6. Check electrical system. Explain fuse box, and battery maintenance.

7. Give practical field demonstration of purchased implements.

8. Explain maintenance of implements in accordance with operation manual.

9. Issue warranty file card, and return to Messrs. Gebrüder Holder.

10. Pay attention to your local traffic and safety regulations

1. Check oil level of engine. (When driving on steep slopes, the oil level should reach the upper mark. Oil quality see column A-2a.

2. Depending on dust development, clean air filter and top-up with fresh engine oil.

3. Check cooling water level.

b) If necessary, depending on operation conditions, check and clean, radiator fins.

c) Check whether air intake rubber part is blocked.

1. Replace filter cartridge.

2. Change oil in engine (according to operation manual)

3. Check valve tolerance (warm and cold 0,25)

4. Retighten cylinder head screws once more with torque wrench set to break at 90 Nm (9,0 kpm.)

2nd Service	3rd Service	4th Service	5th Service
<p>E</p> <p>After every 150 operation hours.</p> <p>If possible, carry out all jobs, and give all explanations, in the presence of the owner, or his authorized person, and the tractor driver.</p> <ol style="list-style-type: none"> 1. Engine <ol style="list-style-type: none"> a) Replace filter cartridge. b) Change engine oil. c) Clean ventilation filter (sealing cover) d) If necessary, clean oil filter, and top-up with fresh oil. e) Check V-belt tension. f) If necessary, blow through radiator fins with compressed air, from inside out. If frost is expected, check cooling water concentration! g) Clean ventilation filter of fuel injection pump. 2. Change gear oil for the first time, thereafter every 1500 operation hours. Front gearbox: A 55 = 7.0 Ltr. (+ 2.0 Ltr. in hydraulic steering and hydraulic system). HD-B SAE 20 engine oil for temperatures below -10° C HD-B SAE 10. 3. Grease all lubrication nipples. 4. Check complete electrical system, incl. battery. 5. Check clutch play, if necessary readjust. 6. Check brakes, if necessary readjust. 7. Retighten all screws, particularly check wheel nuts. 8. Check tyre pressure. 9. Trial run tractor and, if necessary, give another practical field demonstration of the implements. 	<p>F</p> <p>After every 300 operation hours.</p> <p>Latest 6 months after having handed tractor over to client. If possible, all jobs should be carried out, and all explanations given, in the presence of the tractor owner, or his authorized person, and the tractor driver.</p> <ol style="list-style-type: none"> 1. Engine <ol style="list-style-type: none"> a) Check valve tolerance (0.25). (If necessary, replace cork seal of cylinder cap) b) Check oil level of injection pump. Bosch test. 2. Replace fuel filter in tank (do not clean). 3. Change oil in gearbox for the first time, then every 1500 operation hours. (atm.) 4. Rear gearbox: A 55 = 9.0 Ltr. SAE 80 gear oil. 5. Check oil level of reduction gears (if necessary, top-up filler screw SAE 80 gear oil). 5. Steering <ol style="list-style-type: none"> a) Check steering play and, if necessary, reset. b) Check steering angle and stop bolts. 	<p>G</p> <p>After every 600 hours, resp. annually</p> <p>Remove in-</p> <ol style="list-style-type: none"> 1. Engine <ol style="list-style-type: none"> a) Check compression pressure (24 + 2 bar) 2. Check engine clutch. 3. Have injection pump with regulator checked by a Bosch Service Station. Have oil in regulator housing renewed. 4. Steering <ol style="list-style-type: none"> a) Check steering play b) Check according to manufacturers (ZF) instructions. 5. Check pivot axle seat. 6. Retighten all screws. 7. Remove fuel tank and rinse. Fit new filter. 	<p>H</p> <p>After every 2500 operation hours.</p>

If the number of operation hours, as prescribed for the intervals between oil changes, are not reached, the oil must be changed at least once a year.

Lubricating grease

The lubricating grease must neither contain resin, nor acid, or other detrimental compounds. "Stauffer" grease must not be used for lubrication. We recommend lithium-saponified multi-purpose lubricating grease with a penetration quota of 260 to 290.

N) List of possible engine troubles

Troubles	Possible cause	Remedy
Engine does not spring to life.	Empty fuel tank Air in fuel injection system Fuel filter clogged — in winter owing to separation of paraffin Leaking fuel pipes	Refill fuel tank and ventilate fuel pipes. Renew fuel filter Use winter fuel Check all pipe connections for tightness, and retighten screw unions.
Engine proves difficult to start.	Battery capacity insufficient Battery terminals loose and oxidizing Starter turns too slowly. In winter: engine oil too viscous Fuel feed insufficient: fuel system blocked owing to paraffin separations. Coarse leakage of pistons and cylinder heads.	Have battery checked. Clean battery terminals, and apply vaseline-free battery grease Use engine oil according to ambient temperatures. Renew fuel filter. Check pipe connections for leaks, and tighten screw unions. In cold weather, use winter fuel. Have checked by a skilled mechanic.
Engine operates irregularly, and performs badly.	Insufficient fuel feed Air filter system dirty. Relief valve of fuel injection pump not working correctly Required valve tolerance not in order	Replace fuel filter, check pipe connections for leaks, and tighten screw unions. Clean air filter system Have checked by a skilled mechanic Have valve tolerance reset, have valve springs renewed Have checked by an expert mechanic
Exhaust smokes excessively	Nozzle needles jammed Oil level in engine too high Oil level in oilbath air filter too high Bad combustion owing to coked, or broken combustion rings, or incorrect valve tolerance Incorrect injection timing Air filter system dirty	Reduce oil level to upper diprod mark Reduce oil level to mark Have combustion rings and pistons checked by a skilled mechanic. Reset valve tolerance Have checked by an expert mechanic Clean air filter system

se

H

ry 2500 operation ho

compression pressure
bar).
engine clutch.
jection pump with
checked by a Bosch S
. Have oil in regulat
i renewed.
3
steering play
according to manufa
y) instructions.
pivot axle seat.
en all screws.
a fuel tank and rinse
filter.

ter detrimental
We recommend
ation quota of

Troubles	Possible cause	Remedy
Engine overheats	V-belt loose or torn Radiator fins blocked	Check V-belt tension, renew V-belt Blow through radiator fins from inside out, with compressed air Replace thermostat Clean air filter
	Thermostat defective Air filter dirty Injection nozzles defective Delivery of fuel injection pump not precisely adjusted	Have checked by an expert mechanic Have re-adjusted by an expert mechanic
Engine without oil pressure	Leaks in lubrication system	Check screw unions of oil pipes and of lubrication oil filter for leaks, and retighten
Oil pressure warning indicator lights up	Crankshaft bearings too much tolerance Oil pressure warning indicator defective, or faulty electrical conductor	Consult an accredited workshop
Charging lamp lights up during operation	V-belt loose or torn Battery not charged by dynamo because same, or regulator switch, defective	Check V-belt tension, renew V-belt Have checked by a skilled mechanic.
Charging lamp does not light up before starting	Bad cable connections Glowler lamp defective Battery discharged	Tighten battery terminals Check cable connections Have battery checked.

O) Safety Frame/Make Fritzmeier

(Adjustable from wide to narrow track width and vice versa).

For installation of the safety frame principally use the prescribed parts only. Instructions for installation must be strictly observed. By law, and for reasons of safety, deviations are not permissible. To alter the frame from narrow to wide track, displace sockets with fenders accordingly on the axle housings. On the safety frame, the angle tubes (E) must be fitted as shown on Ill. 18, and the clamping clips (K) must be newly bored.

1. Installation of the support tubes (Ill. 18)

Insert the lefthand frame support (A) and the righthand frame support (B) in the sockets of the axle housing. The retaining shackles with shims (C) must be flush with the fenders. As shown on Ill. 19, insert the 2 tubes (D) also in the sockets of the axle housing. Using ovalhead screws M 12x70, screw frame supports (A + B), as well as tube (D) onto the axle housing sockets (do not tighten)!

Screw angle tube (E) onto left and right frame support by means of oval-head screws (M 12x70). Do not tighten!

Attention: Pay attention to the different possibilities of installation (narrow or wide track). Screw tubes (F) also onto angle tube by means of oval-head screws M 12x70 (do not tighten)!

2. Installation of the top of the safety frame

Rub talcum powder or something similar into the neck protection (G). Then slide it onto the tube of the right half of the frame (H/R). Fit both halves of the frame together (check measurement 1090 mm).

Fit crown of frame with front clamping clips (I) in available bores by means of oval-head screws M 12x70 (do not tighten)!

Attention! The available bores (X, Ill. 19) must be positioned from low at the outside, upwards at the inside. Now fit top of frame with rear clamping clips (K) as well. Use oval-head screws M 12x70, but do not tighten! The now loosely assembled top of the frame must be aligned so that the width of 1090 mm (Ill. 18) is maintained (measurement taken from centre to centre of tube). The measurement of the top of the frame overlapping the tractor in front is 183 mm (Ill. 19) (measured from the centre of the top tube to the extreme edge of the clamping clip).

5. Final assembly

If the crown of the frame has been aligned according to the required measurements, the top and retaining shackles can be bored up (13 mm dia.), and then all screws can be tightened with torque wrench set to break at 70 Nm (7 kpm). Care must be taken that all screw heads point inwards. With the exception of the 2 screws in the centre of the frame (X Ill. 19) which must be fitted in a way to permit slackening of their nuts inside on top. Fit the supplied plastic caps over these nuts.

Attention! For safety's sake, the self-locking screws can be used once only!

P) Assembly of the 3-way Valve 5080/1 (Ill. 17).

For additional, hydraulically operated implements, a 3-way valve with clamping sleeve can be installed. Remove seat with seat base. Disconnect pressure pipe between control valve and distributor. Assemble pressure pipe (1012 Ill. 17) from distributor to three-way valve, and pressure pipe (1013 Ill. 17) from control valve to three-way valve. Reassemble seat with base. Screw three-way valve (1015 Ill. 17) with retainer to the seat base.

1	Comb
2	Tract
3	Hand
4	Foot f
5	Blinke
6	Gear s
7	Select
8	Adjust
9	Hand l
	operat
10	Clutch
11	Threac
12	Collar
13	Set scr
14	Set sci
15	Ignitic
16	Glow :
17	Warnin
18	Glow :
19	Fuse t
a	Fuse -
b	Fuse -
c	Fuse -
d	Fuse -
e	Fuse -
	transr
20	Socket
21	Chargi
22	Oil pre
23	Blinke
24	Blinke
25	Tempe
26	Hydra
27	P.T.O.
28	Brake

d retaining
h set to
option of
eening of

installed.
assemble
) from con-
with retai-

Ill. No.	Description	Ill. No.	Description	Ill. No.	Description
1	Combined control instrument	29	Foot gas pedal	66	Radiator drain screw (engine)
2	Tractormeter	30	Brake pedal	67	Change oil filter
3	Hand throttle lever	31	Machine serial No.	68	Engine serial No.
4	Foot pedal for front diff-lock	32	Type plate	69	Air filter insert
5	Blinker light switch	33	Hand brake lever	70	Oil basin for air filter
6	Gear selector lever	34	Cut-out lever	71	Stop bolt
7	Selector lever (preselection)	35	Horn button	72	Stud for steering angle
8	Adjustment lever for seat springing	36	Fuel tank	73	Hydraulic lever
9	Hand lever for rear diff-lock operation	37	Battery	74	Check chains
10	Clutch pedal	38	Tool box	75	P.T.O. shaft
11	Thread piece (clutch cable)	40	Horn	76	Trailer socket
12	Collar nut	41	Ventilation filter (injection pump)	77	Upper linkage arm
13	Set screw for brake adjustment	42	Oil diprod	78	Three-chamber rear reflector
14	Set screw for steering play	43	Oil filter plug	79	Crank handle for adjustment spindle
15	Ignition with ignition key	44	Cyclone presselector	80	Trailer hitch with pistol-type handle grip
16	Glow starter switch	45	Air intake rubber part	82	Glow plug
17	Warning light impulse transmitter	46	Radiator cap	83	Counter nut for valve adjustment screw
18	Glow starter indicator	47	Air filter	84	Feeler gauge
19	Fuse box	48	Tractormeter drive shaft	85	Distributor piece
a	Fuse - blinker light	49	Overflow control screw	86	Oil drain screw
b	Fuse - brake light	50	Fuel injection pump	E1	Filler plug (engine)
c	Fuse - parking light, left	51	Ventilation screw (injection pump)	E2	Filler sight glass (front gearbox)
d	Fuse - parking light, right	52	Blinker light	E3	Filler screw (rear gearbox)
e	Fuse - warning light impulse transmitter	56	Temperature indicator	A1	Drain screw (engine)
20	Socket	57	Exhaust	A2	Drain screw (front gearbox)
21	Charging lamp	58	Thermostat	A3	Drain screw (rear transmission)
22	Oil pressure indicator	59	Cooling water pump	Aw	Drain screw (radiator)
23	Blinker pilot light/tractor	60	V-belt	K	Control plug (reduction gears) resp. sight glass (rear gearbox)
24	Blinker pilot light/trailer	61	Screws for adjustment shackle (dynamo)	S	Lubrication nipples
25	Temperature indicator	62	Dynamo	SK	Lubrication nipple in yoke
26	Hydraulic operation lever	63	Screws for dynamo support	Y	Ratchet lever
27	P.T.O. selector lever	64	Starter		
28	Brake light switch	65	Oil pressure control switch		

Single-drum Forestry Rope Winch Type Holder 5073-2

Make Schlang and Reichart

Operation Instructions

Technical data:

Wire rope optionally \varnothing 9 mm x 70 m (breakload 7.500 kg), or \varnothing 11 mm x 50 m (breakload 10.800 kg).

Payload and rope speed at a P.T.O. speed of 540 min⁻¹ (rpm)

Payload (kg)	Lower rope position	Medium rope position	Upper rope position
	5000	4000	3600
Rope speed m/sec.	0,45	0,55	0,65

Operation:

Place tractor in direction of pull. Angular deviations up to 75° are possible, though the full pulling capacity must no longer be used.

1. Lower three-point hydraulics, and, in consequence, the butt plate.
2. Engage P.T.O.
3. Release brake of winch by means of hydraulic operation lever. Unwind wire rope and fit load. Avoid loops and sharp angles!
Unwinding of the rope is braked on the rope drum by means of a small sliding brake, and can be adjusted by means of the laterally situated screw (188 Ill. 30).

4. a) Winding up rope in normal operation (P.T.O. engaged)

To wind up the rope, operate the cable control against pull-off spring — clutch of winch closed. When released, the control lever is guided into „0“ position by means of the return spring. The rope drum is automatically braked.

b) Winding up rope with a very careful pull.

Depress clutch pedal of tractor, engage P.T.O., close clutch of the winch by means of the guide lever (102 Ill. 23) and start using the tractor clutch.

c) Slow starting by means of the clutch, and slow release of the brake, is permitted if the hand lever of the winch control is very carefully operated. However, in this way, the clutch, resp. brake plates, are forced to slide — hence increased wear.

If, with a heavy load, or when meeting an obstacle, the clutch of the winch slides, the rope must be slackened before making a renewed trial. Each repeated pull with a tight rope will considerably reduce the pulling power and will cause unnecessary wear and heating of the clutch.

Clutch and brake must be left sliding for very short intervals only.

When not using the winch for longer intervals (e.g. road drive), disengage the P.T.O.

Service and Maintenance

Lubricate the grease nipple of the swivel pulley once a week with grease. Change oil in gearbox (2,5 ltr. GX 140) for the first time after 50, thereafter every 200 operation hours. We strongly recommend to use only oils of the SAE 140 class. Oil drain screw (115 Ill. 30), filler screw (116 Ill. 30).

This installation of the winch permits the attachment of a trailer by means of the standard trailer hitch (119 Ill. 31) and, when removing the butt plate, the 3-point linkage and P.T.O. (117 Ill. 31) can be used (e.g. for attachment of a rotary cultivator (Ill. 32). Thereby use mounting plate (120 Ill. 32), part No. A20 060 A29.

Unwinding of the rope is braked on the rope drum by means of a small sliding brake, and can be adjusted by means of the laterally situated screw (118 Ill. 30).

Double-drum Forestry Rope Winch Type Holder 5073-7

Make Schlang and Reichart

Operation Instructions

Technical data

Wire rope optionally \varnothing 9 mm x 70 m (breakload 7.500 kg), or 11 mm \varnothing x 50 m (breakload 10.800 kg).

Payload per drum and rope speed at 540 min⁻¹ (rpm)

	Lower rope position	Centre rope position	Upper rope position
Payload kg	3000	2500	2200
Rope speed (m/sec.)	0,45	0,55	0,65

Operation

Place tractor in direction of pull. Angular deviations up to 90° are possible, though the full pulling capacity must no longer be used.

1. Lower butt plate (100 Ill. 22) by means of operation lever (101 Ill. 23) and press it into the soil.
2. Engage P.T.O.
3. Release brake of the winch by means of hydraulic operation lever (102 Ill. 23). Unwind wire rope and fit load. Avoid loops and sharp angles!
Unwinding of the rope is braked on the rope drum by means of the laterally situated slot screw (114 Ill. 25).

4. a) Winding up rope in normal operation (P.T.O. engaged)

To wind up the rope, operate the winch control (102 Ill. 23) against pull-off spring. When released, the control lever is guided to „0“ position by means of the return spring. The rope drum is automatically braked.

b) Winding up rope with a very careful pull

First close clutch of the winch (102 Ill. 23), engage P.T.O. and start by means of the P.T.O. clutch.

c) Very careful operation of the winch control lever (102 Ill. 23) permits slow starting with the clutch of the winch, and a slow release of the brake. However, clutch, resp. brake plates, are thereby forced to slide — increased wear.

If with a heavy load, or when meeting an obstacle, the clutch of the winch is caused to slide, the rope must be slackened for a renewed trial. Each repeated pull with **tightened** rope will considerably reduce the pulling capacity and cause unnecessary wear and heating of the clutch.

Let clutch and brake slide for very short intervals only!

When not using the winch for longer intervals (e. g. road drive), disengage the P.T.O.

Service and Maintenance

The rotating point of the rocker bracket (104 Ill. 24), the bearings of the hydraulic cylinder, and the bevel pinion shafts, must be kept free from dirt and protected from corrosion and seizure by a permanent oil film.

Grease once a week the two grease nipples of the butt plate linkage points (106 Ill. 25) and the swivel pulleys (107 Ill. 24), as well as the lubrication nipple of the hitch. Check oil filling in bevel gear (108 Ill. 27 + 134 Ill. 28), and worm gear transmission (109 Ill. 25) on the oil level control screw.

Change oil in worm gear transmission for the first time after 50 hours, thereafter every 200 hours of operation. Filling quantities and brand of oil (SAE 140 only) can be read off the oil plate.

1.0 l, e.g. Mobilube GX 140, ARAL oil BG 98, BP gear oil EP SAE 140, ESSO gear oil Sp 140, SHELL gear oil 140.

Oil drain screw (110 Ill. 26), filler screw (111 Ill. 28), control screw (109 Ill. 26).

Change oil in bevel gearbox for the first time after 500 hours, thereafter every 1000 hours of operation.

Filling quantities and brands of oil are indicated on the oil plate.

0,25 l e.g. MOBILGEAR 629, ARAL oil BG 28, BP gear oil EP SAE 90, ESSO gear oil GP 90, SHELL gear oil 90.

Oil drain screw (112 Ill. 27), filler screw (113 Ill. 27), control screw (108 Ill. 27).

Change oil in small bevel gearbox for the first time after 500 hours, thereafter every 1000 hours of operation. Filling quantities and brand of oil can be read off the oil plate.

0,25 ltr. e.g. Mobilgear 629, Aral oil BG 28, gear oil EP SAE 90, Esso gear oil GP 90, SHELL gear oil 90.

Filler and drain plug (134 Ill. 90).

When changing oil, the old oil must be sucked off. To do so, unscrew plug (134 fig. 28).

Hydraulic oil supply tank (130 Ill. 25)

Change oil for the first time after 500 hours of operation, thereafter every 1500 hours.

2,5 ltrs. hydraulic oil Mobil Vac HL P 36.

Clean oil filter (131 Ill. 25) for the first time after 50 hours, thereafter every 500 hours.

Drain hydraulic oil by slackening the swivel screw union (132 Ill. 25). Filler plug (133 Ill. 25).

At the occasion of each regular service, have all screws examined for tight fit.

Instructions for handling the wire rope

The wire ropes supplied by us have been tested by the manufacturers for their breakload and rechecked by us for proper condition. On the ground of these tests (test certificates available) claims for replacement must be principally rejected.

Each wire rope is made additionally anti-corrosive and receives a coating of dry lubricant through immersion or spraying with a fast-drying sliding agent which, already a few minutes after its application, prevents the adhesion of dirt and sand, e.g. Molykote 165 X. A clean wire rope is a prerequisite for this treatment.

When fitting a new rope, the rope must be unwound from the rope ring. Each loop caused by lateral unwinding, or by pulling, will damage the rope.

One end of the rope is fitted in the rope drum by means of a clamping wedge — the other end has a loop with sliding hook for fitting the load. Instead of the loop with sliding hook, a wedge lock with clamping wedge and draw hook can be used.

Before first use, and before handling heavy loads, we recommend to unwind the rope until only 3 layers remain, to hook one end into a firm point, and to pull, with slightly closed handbrake, the tractor back to the firm point. This initial tension of the rope will create a smooth „package of rope“ which will not be cut into by overlaying layers of rope — damages can in this way be avoided to a large degree.

Should, in one or the other event, the pulling capacity of the rope prove insufficient, a reversing pulley will help to double it (with half the pulling speed). Thereby, the end of the rope with the draw hook must not be fitted on the tractor, but another firm point must be found (e.g. another tree).

As an option, the double-drum forestry rope winch can be supplied with keyboard control or with radio control.

Operation of keyboard control (Ill. 33).

The controls for unwinding and winding up of the rope have different colours for each drum.

Drum 1

Unwinding cable rope: Press key (122 Ill. 33) and fix by turning it.

Winding up rope: the key for unwinding the rope must be back to „0“ position. The cable rope is wound up by means of pressing the key (124 Ill. 33). When releasing the key, winding up stops and the drum is automatically braked. The speed is adjusted by pressing the key (121 Ill. 33) which also can be fixed in position by turning it.

The same procedure applies to drum 2.

Radio control

Special instructions must be observed which please apply for if necessary.

Transporting stacked logs

Prepare the logs as shown on Ill. 34. Reverse the tractor till it has reached the pile of logs. Lower the butt plate. Lock stirrup with rope pulleys in uppermost position. Wind the ropes around the pile of logs as shown on Ill. 34 and hook them to the butt plate. (See Ill. 35). Pull in the ropes uniformly, then lift the butt plate.

Attention: Take care not to hit the rope pulleys.

Front-mounted Rolling and Stacking Blade Type 5036-1 or 5036-2








Ill. 36 shows type 5036-2 which differs from Ill. 5036-1 by being equipped with a double-acting hydraulic cylinders (128 Ill. 36) instead of the rigid connecting rod. The type 5036-2 has an additional adjustment possibility for the blade out of its horizontal position.

Operation

Levers (126 and 127 Ill. 36) operate the front-mounted rolling and stacking blade via the control valve and the hydraulic cylinder.

Maintenance:

Grease the lubrication nipples (S Ill. 36) once a week.



NOTIZEN

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are approximately 20 lines visible. The paper appears to be from a notebook or a standard sheet of stationery. There is no handwriting or other markings on the page.



Abb. 25




Abb. 27




Abb. 26



Abb. 28




Abb. 33




Abb. 34




Abb. 35




Abb. 36




Abb. 38

Abb. 38 Schaltplan zur Doppeltrommel-Forstseilwinde Type 5073-7.
Control diagramme of double-drum forestry winch type 5073-7.
Diagramme de contrôle pour treuil jumelé type 5073-7.
Diagrama de control del torno gemelo de cable tipo 5073-7.




Abb. 39

Abb. 39 Schaltplan zur Bergstütze der Doppeltrommel-Forstseilwinde.
Control diagramme of butt plate for winch type 5073-7.
Diagramme de contrôle pour la lame du treuil jumelé.
Diagrama de control del pala del torno gemelo de cable.



Abb. 1




Abb. 2




Abb. 3




Abb. 4




Abb. 4a




Abb. 6




Abb. 8




Abb. 5




Abb. 7




Abb. 15a





Abb. 15



NOTIZEN

